Argonne Pational Laboratory

SOME APPLICATIONS OF SCINTILLATION SPECTROMETRY TO NONDESTRUCTIVE TESTING

by

Ronald B. Perry

LEGAL NOTICE

This report was prepared as an account of Government sponsored work. Neither the United States, nor the Commission, nor any person acting on behalf of the Commission:

- A. Makes any warranty or representation, expressed or implied, with respect to the accuracy, completeness, or usefulness of the information contained in this report, or that the use of any information, apparatus, method, or process disclosed in this report may not infringe privately owned rights; or
- B. Assumes any liabilities with respect to the use of, or for damages resulting from the use of any information, apparatus, method, or process disclosed in this report.

As used in the above, "person acting on behalf of the Commission" includes any employee or contractor of the Commission, or employee of such contractor, to the extent that such employee or contractor of the Commission, or employee of such contractor prepares, disseminates, or provides access to, any information pursuant to his employment or contract with the Commission, or his employment with such contractor.

ANL-6743 Reactor Technology (TID-4500, 30th Ed.) AEC Research and Development Report

ARGONNE NATIONAL LABORATORY 9700 South Cass Avenue Argonne, Illinois 60440

SOME APPLICATIONS OF SCINTILLATION SPECTROMETRY TO NONDESTRUCTIVE TESTING

by

Ronald B. Perry

Metallurgy Division Program 12.1.4

March 1964

Portions of the material included in this report have appeared in the following Metallurgy Division Progress Reports:

Report No.	Pages	Date	
ANL-6330	132,133	1960	
ANL-6516	191,192	1961	

Operated by The University of Chicago under Contract W-31-109-eng-38 with the U. S. Atomic Energy Commission ANE-6793

Restor Lecenterous

(YMD-4500, 20th Education

(YMD-4500, 20th Education

ANE Research and

Dovelopment Restor

ARGONG NATIONAL LABORATORY
9700 SOuth Grantes Arguments and Arguments an

SOME APPLICATIONS OF SCHTLIGHTION SPECTROMETRY
TO NO VOLUME HEATING

Tropies of Stanon

Eld margor Trotale Gog tottle

Acrib district

Postions of the majorus durindes in this report has a inferring in the following Metalliers; Division Progress Reports:

Operated by The University of Chiefs
incide
Contract v - 34 - 162 - ong 436

U. S. Atomic Street Commission

TABLE OF CONTENTS

		Page
ABS	STRACT	3
I.	INTRODUCTION	3
II.	U ²³⁵ ASSAY PROCEDURE	6
	A. Static Method	6
	B. Two-dimensional Scanning Method	8
III.	DISCUSSION OF APPLICATIONS	10
IV.	URANIUM DISTRIBUTION IN DISPERSION AND ALLOY FUELS	12
REE	TERENCES	12

TABLE OF CONTENTS

LIST OF FIGURES

No.	<u>Title</u>	Page
la.	Gamma-ray Spectrum of Uranium Enriched in U ²³⁵	4
lb.	Gamma Spectrum - Normal Uranium	4
lc.	Gamma-ray Spectrum of Uranium Enriched in U^{234}, \ldots	5
ld.	Gamma-ray Spectrum of Uranium Enriched in U^{236}, \ldots, \ldots	5
2	Intensity of 184-keV Gamma Ray as a Function of U ²³⁵ Enrichment	6
3.	Gamma-ray Spectra of Uranium Foils of Various U ²³⁵ Enrichments	6
4.	Experimental Procedure U ²³⁵ Analysis Scintillation Spectrometry	7
5.	${\bf Self-absorption} \ \ {\bf Relation} \ \ {\bf for} \ \ {\bf Exponentially} \ \ {\bf Absorbed} \ \ {\bf Radiation} \ .$	7
6.	Total Scanning Technique U ²³⁵ Assay of Fuel Elements by Scintillation Spectrometry	9
7.	Equipment for Two-dimensional Scanning of Fuel Plates	9
8.	Calibration Curve Obtained by Two-dimensional Scanning	10
9.	Equipment for Linear Scanning of Fuel Plates	11
	LIST OF TABLES	
No.	<u>Title</u>	Page
I.	Comparison of Destructive and Nondestructive Analysis	8
II.	Measured U ²³⁵ Loading Compared with Fabrication Data for BORAX-V Superheater Plates	11

LIST OF FIGURES

Calibration Curve Obtained by Two-dimensional Scapning	

SOME APPLICATIONS OF SCINTILLATION SPECTROMETRY TO NONDESTRUCTIVE TESTING

by

Ronald B. Perry

ABSTRACT

Gamma-ray scintillation spectrometry is a useful tool for the nondestructive assay of the U²³⁵ content of research reactor fuel. The U²³⁵ is the only isotope of uranium that produces a strong peak of gamma energy at 184 keV. Accordingly, the U²³⁵ content of reactor fuel can be accurately determined by counting the 184-keV gamma emission.

Uranium foil standards of known weight and isotopic content can be used for assay of fabricated reactor fuel with a product of density and thickness small enough to permit accurate measurement of the self-absorption factor. Two techniques for nondestructive assay of fabricated fuel in flat configurations, based on the use of uranium foils as standards, are discussed herein. In the first method a small area is counted and homogeneity is assumed. In the second method, a two-dimensional scanning technique is employed such that the entire sample is counted. A similar scanning technique has been used for tubes of 5.08- to 7.62-cm diameter.

Other configurations of reactor fuel have products of density and thickness or geometrical shapes that do not permit accurate measurement of the self-absorption factor for the 184-keV gamma. Standard samples for these configurations may be taken from the material itself and standardized by mass-spectrometric and chemical analysis or specially fabricated from material of known U²³⁵ content.

Scintillation counting techniques may be applied to other reactor fuel testing problems. Distribution of U²³⁵ in dispersion and alloy-type fuels can be measured by counting small areas with a well-collimated detector.

I. INTRODUCTION

Gamma-ray scintillation spectrometry provides a nondestructive method of reactor fuel assay for U^{235} content which is useful for quality

SOME APPLICATIONS OF SCINTILLATION SPECTROMETRY TO NONDESTRUCTIVE TESTING

yd

Ronald B. Perry

ABSTRACT

Gamma-ray scintillation spectrometry is a useful tool for the nondestructive aseay of the U⁽³⁾ content of research reactor fuel. The U⁽³⁾ is the only isotope of uranium that produces a strong peak of gamma energy at 184 keV. Accordingly, the U⁽³⁾ content of reactor fuel can be accurately determined by counting the 184-keV gamma emission.

Uranium foil standards of known weight and isotopic content can be used for assay of fabricated reactor fuel with a product of density and thickness small enough to permit accurate measurement of the self-absorption factor. Two techniques for nondestructive assay of fabricated fuel in flat configurations, based on the use of uranium foils as standards, are discussed herein. In the first method a small area is counted and homogeneity is assumed. In the second method, a two-dimensional scanning technique is employed such that the entire sample is counted. A similar scanning technique has been used for tubes of 5.08- to 7.64-cm diameter.

Other configurations of reactor feel have products of density and thickness or geometrical shapes that do not permit accurate measurement of the self-absorption factor for the 184-keV gamina. Standard samples for these configurations may be taken from the material itself and standardized by mass-spectrometric and chemical analysis or specially fabricated from material of known U³³ content.

Scintillation counting techniques may be applied to other reactor fuel testing problems. Distribution of U22 in dispersion and alloy-type fuels can be measured by counting small areas with a well-collimated detector.

L INTRODUCTION

Gamma-ray scintillation spectrometry provides a nondestructive method of reactor fuel assay for U³²⁵ content which is useful for quality

control and accountability purposes. In a sample of highly enriched uranium containing 93% U²³⁵, 5.5% U²³⁸, 1% U²³⁴, and 0.5% U²³⁶, the U²³⁵ isotope contributes only 3% of the total disintegrations. But examination of the gamma-ray spectra of various uranium isotopes (see Figures la, lb, lc, and ld) indicates that the U²³⁵ isotope is the primary source of gamma radiation of 184-keV energy. In normal uranium the U²³⁵ isotope produces approximately 2% of the disintegrations, but its presence is still detectable from the gamma-ray spectrum (see Figure lb). The intense peak of gamma energy at 184 keV from the decay of U²³⁵ is especially useful for U²³⁵ assay. Procedures for quantitative measurement of U²³⁵ content in reactor fuels based on counting the 184-keV gamma from U²³⁵ by means of a single-channel scintillation spectrometer with a NaI(T1) crystal detector have been established.





Figure la Gamma-ray Spectrum of Uranium Enriched in U²³⁵

670-526 Rev.

GAMMA SPECTRUM-NORMAL URANIUM

Figure 1b Gamma Spectrum -Normal Uranium



670-520 Rev.

control and accountability purposes. In a sample of highly enriched uranium fontaining 95% U ** 5.5% U ** 1% U ** and 0.5% U ** the U as the U ** the U ** and 0.5% U ** the Examination of the gamma-ray spectra of various aranium isotopes (see Figures Ia, Ib, In. adiation of 184-keV energy in normal uranium the U ** the primary source of gamma approximately 25% of the disintegrations, but its presence is still detectable from the gamma-ray spectrum (see Figure 1b). The intense peak of gamma energy at 184 keV from the decay of U ** is especially useful for U ** assay. Procedures for quantitative measurement of U ** content in reactor field based on counting the 184-keV gamma from U ** is in the single-charmal scintillation spectrometer with a Walf (F) crystal detector have been established.




Figure is Camma-ray Spectrum of Uranium Enriched in U³⁵



Gamma Spectrum -Normal Uranium

670-520 Rev.





Figure 1c. Gamma-ray Spectrum of Uranium Enriched in U²³⁴



 $\label{eq:Figure 1d} Figure \ 1d \\ Gamma-ray \ Spectrum \ of \\ Uranium \ Enriched \ in \ U^{236}$

670-525 Rev.

The graph in Figure 2 shows there is a linear relationship between the intensity of the 184-keV gamma and the quantity of U²³⁵ in the source. The quantity of uranium has been kept constant so that the self-absorption is the same for each sample. As shown in Figure 3, in which the spectra of sources containing various amounts of U²³⁵ are superimposed, the entire gamma-ray spectrum up to 300 keV decreases as the amount of U²³⁵ in the source decreases. The spectra were produced under the same conditions with sources of approximately the same weight.






Figure Ic. Gamma-ray Spectrum of Uranium Enriched in U²³⁴.




The graph in Figure 2 shows there is a linear relationship between the intensity of the 184-keV gamma and the quantity of U²² in the source. The quantity of uranium has been kept constant so that the self-absorption is the same for each sumple. As shown in Figure 3, in which the spectra of sources containing various amounts of U²⁵ are superimposed, the entire gamma-ray spectrum up to 300 keV decreases as the amount of U²⁵ in the source decreases. The spectra were produced under the same conditions with sources of approximately the same weight.



II. U²³⁵ ASSAY PROCEDURE

A. Static Method

Fuel configurations with density-times-thickness products small enough to permit accurate measurement of the self-absorption factor for the 184-keV γ radiation from U²³⁵ can be compared with standard uranium foils of knownweight and isotopic content. (1) This technique is applicable



II. UZE ASSAY PROCEDURE

A. Static Method

Tuel configurations with density-times-thickness products small enough to permit accurate measurement of the self-absorption factor for the 184-keV y radiation from U²¹⁵ can be compared with standard transfer fells of known weight and isotopic content (1). This technique is applicable.

to thin plates containing an uranium alloy or dispersion. Cladding of approximately the same thickness on both sides of the sample will not affect the results.

A technique for counting the samples and measuring the self-absorption is shown in Figure 4. The detector is shielded and collimated with lead so that only the area under the collimator is counted. The three count rates obtained in steps 1-3 in Figure 4 are used to calculate the absorption factor μ t of the sample from the equation for exponential absorption given at the bottom of Figure 4. The count rate of the sample is corrected for self-absorption by means of the equation given in Figure 5. The self-absorption correction for the standard foil would be determined in a similar manner and would then be a known constant.




Figure 4

Experimental Procedure U²³⁵ Analysis Scintillation Spectrometry

106-5988 Rev.

 $\frac{C_t}{C_0} = \frac{1 - e^{-\mu t}}{\mu t}$

Figure 5

Self-absorption Relation for Exponentially Absorbed Radiation where:

 C_0 = Activity of source with no self absorption

 ${
m C_t}$ = Activity of source with self absorption having thickness t and absorption coefficient μ

106-5990

to thin plates containing an uranium alloy or dispersion. Cladding of approximately the same thickness on both sides of the sample will not offect the results.

A technique for counting the samples and measuring the selfabsorption is shown in Figure 4. The detector is shielded and collimated
with lead so that only the area under the collimator is counted. The three
count rates obtained in steps 1-3 in Figure 4 are used to calculate the absorption factor at the sample from the equation for exponential abacryption given at the bottom of Figure 4. The count rate of the Sample is
corrected for self-absorption by means of the equation given in Figure 5.
The self-absorption correction for the standard foil would be determined
in a similar manner and would then be a known constant.



Figure 5

Self-absorption Relation or Exponentially Abarbed Radiation

149-1 to

sale div

Co = Activity of source with no self absorption

 Activity of source with self absorption having thickness 1 and absorption coefficient qu The ratio of the corrected count rates for the standard foil and sample are equal to the ratio of their respective disintegration rates in the area under the collimator. The quantity of U^{235} in a unit area of the sample is then determined by direct proportion. The U^{235} content of the entire sample can be calculated by measuring the area of the sample and assuming the sample to be homogeneous. The area of clad samples may be measured from a radiograph. An example of the accuracy obtainable by this technique is given in Table I. The plates numbered 605, 598, and 500C were assayed by averaging the results of 15 counts taken over different areas on each plate.

Table I

COMPARISON OF DESTRUCTIVE AND NONDESTRUCTIVE ANALYSIS

		U ²³⁵ Content, g		
	Plate Number	Gamma Counting, Static Method	Chemical and Mass-spectrometric Analysis	From Fabrication Data
High Flux Reactor	605	15.10 ± 0.30	15.07 ± 0.08	Not available
	598	18.43 ± 0.37	18.17 ± 0.11	Not available
	500C	4.24 ± 0.08	4.10 ± 0.02	Not available
Juggernaut	AD-9	17.01 ± 0.08*	16.953	17.01
	AP-11	17.74 ± 0.12*	17.735	16.68

^{*}Scanning method

B. Two-dimensional Scanning Method

A second method, which eliminates two possible sources of error in the first method but requires more equipment, is based on a two-dimensional scanning technique. (2)

The technique is shown diagrammatically in Figure 6. A lathe, with the detector mounted on the cross feed, and the single-channel scintillation spectrometer used for scanning fuel plates are shown in Figure 7. The counting time is determined by the scanning speed of two orthogonal components of motion. In this method homogeneity need not be assumed and measurement of the area is not required. The resulting count accumulated during scanning is proportional to the area as well as the intensity of the source. The self-absorption corrections are calculated in the same manner as in the first method.

An example of a calibration curve obtained by two dimensional scanning for stainless steel-clad BORAX-V superheater plates with four

The ratio of the corrected count rates for the standard foil and sample are equal to the ratio of their respective disordegration rates in the area under the collimator. The quantity of U.S. in a unit area of the sample is then determined by direct proportion. The U.S. content of the ontere sample can be calculated by measuring the area of the sample and assuming the sample to be homogeneous. The area of clad samples may be measured from a radiograph. An example of the accuracy obtainable by this technique is given in Table 1. The plates numbered 505, 598, and 500C were assayed by averaging the results of 15 counts taken over different areas on each plate.

Table 1

COMPARISON OF DESTRUCTIVE AND NONDESTRUCTIVE ANALYSIS

B. Two-dimensional Scanning Method

A second method, which eliminates two possible sources of error in the first method but requires more equipment, is based on a two-dimensional scanning technique (2)

The tochnique is shown disgrammatically in Figure 5. A lathe, with the detector mounted on the cross feed, and the single-channel scimtillation spectrometer used for scanning fuel plates are shown in Figure 7. The counting time is determined by the scanning speed of two orthogonal components of motion. In this method homogeneity need not be assumed and measurement of the area is not required. The resulting count accountated during scanning is proportional to the area as well as the intensity of the source. The self-absorption corrections are calculated in the same manner as in the first method.

An example of a calibration curve obtained by two dimensional acanning for stainless steel-clad BORAX-V superheater plates with foor

different core loadings is shown in Figure 8. The lower curve is the observed count rate as a function of core loading; the upper curve shows the count rate after correction for self-absorption as a function of core loading. The accuracy of the self-absorption correction is indicated by the fact that the points fall on a straight line passing through the origin.





Figure 6

Total Scanning Technique U²³⁵
Assay of Fuel Elements by
Scintillation Spectrometry



106-5732

Figure 7. Equipment for Two-dimensional Scanning of Fuel Plates






Figure 8

Calibration Curve Obtained by Two-dimensional Scanning

A modification of the two-dimensional scanning method has been applied to CP-5 type aluminum clad aluminum-uranium alloy tubes of 5.08- to 7.62-cm diameter. The tube is revolved on centers in a lathe while the detector scans along its length. A cylindrical lead absorber inside the tube permits the detector to measure gamma radiation from the detector side of the tube only. Standard foils mounted on a concentric cardboard tube are used to measure the self-absorption. A constant error of about 1% was encountered in this case. Further development would be necessary to make this procedure reliable for the tubular geometry.

150-324

III. DISCUSSION OF APPLICATIONS

If an entire reactor loading is to be assayed for U^{235} content, only a few plates need be standardized by one of the above methods. The balance of the plates can be compared with these standards. If the samples are small, they can be counted with a fixed geometry and the detector integrates the gamma flux over the area of the source. This technique gave satisfactory results for ALPR core blanks having dimensions of 17.463 x 8.41 cm when a 6.35-cm-diameter detector was used. (3)

The gamma flux from the entire area of a fuel plate can be integrated by the detector by moving the plate beneath the detector at a linear rate. The arrangement used for the Juggernaut loading and for BORAX-V superheater plates is shown in Figure 9. The larger detector in the figure was an alpha scintillator used for detecting radioactive surface contamination. Table I gives results obtained by scintillation spectrometry for individual fuel plates compared with chemical and mass spectrometer




Figure a
Calibration Curve Obtained
by Two-dimensional Scanning


A modification of the two-dimensional scanning method has been applied to CP-5 type sluminum clad aluminum-uranium alloy tubes of 5.08- to 7.62-cm diameter. The tube is revolved on centers in a lathe while the detector scans along its length. A cylindrical lead absorber inside the tube permits the detector to measure gamma radiation from the detector side of the tube only. Standard folls mounted on a concentric cardboard tube are used to measure the self-absorption. A constant error of about 1% was encountered in this case. Further development would be necessary to make this procedure reliable for the tubular geometry.

III DISCUSSION OF APPLICATIONS

If an entire reactor loading is to be assayed for U^{DS} content, only a few plates need be standardized by one of the above methods. The balance of the plates can be compared with these standards. If the samples are small, they can be counted with a fixed geometry and the detector integrates the gamma flux over the area of the source. This technique gave satisfactory results for ALPR core blanks having dimensions of 12.463 x 8.41 cm when a 6.35-cm-diam-ter detector was used.(3)

The gamma flux from the entire area of a fuel plate can be intergrated by the detector by moving the plate beneath the detector at a linear rate. The arrangement used for the Juggernaut loading and for BORAX-V superheater plates is shown in Figure 9. The larger detector in the figure was an alpha equitillator used for detecting radioactive surface contamination. Table I gives results obtained by scintillation spectrometry for individual fuel plates compared with chemical and mass spectrometer

analysis and fabrication data. Table II summarizes the results for an entire loading compared with fabrication data. (4)



106-5730

Figure 9. Equipment for Linear Scanning of Fuel Plates

Table II

MEASURED U²³⁵ LOADING COMPARED WITH FABRICATION DATA FOR BORAX-V SUPERHEATER PLATES

	Number of Plates	U ²³⁵ Content, g			
Type of Loading		Gamma Counting	Fabrication Data	% Deviation	
HCE FCE HPE FPE	186 186 226 226	2,797.66 5,185.99 5,334.21 10,012.73	2,783.57 5,240.24 5,341.89 9,974.47	+0.51 -1.04 -0.14 +0.38	
Total	824	23,330.59	23,340.17	0.04	

Fuel elements with large density-times-thickness products or complicated configurations cannot be standardized with uranium foils. If a large number of samples are to be nondestructively analyzed, it is usually



not objectionable to sacrifice several samples for destructive analysis. An alternative method of standardization is fabrication of standard fuel elements or simulated fuel elements. For example, standards for 0.0762-cm-diameter aluminum-uranium alloy wire were made by absorbing uranyl nitrate solution into nylon string of the same diameter. If the range of U²³⁵ content is not more than 5 to 10% from the average, two standards are usually sufficient for calibration. If the range is much larger a linear function cannot be assumed and additional standards are necessary.

IV. URANIUM DISTRIBUTION IN DISPERSION AND ALLOY FUELS

Distribution of uranium in dispersion or alloy-type fuels can be measured by scintillation spectrometry by counting small areas of the fuel and comparing the count rate with the average count rate. The average count rate for the sample can be determined by scanning the entire sample. For measuring the distribution of uranium it is advantageous to use the entire gamma spectrum, so that the desired accuracy can be obtained in the shortest counting time. A disadvantage of the technique is that thickness changes cannot be distinguished from inhomogeneity in the dispersion or alloy.

REFERENCES

- White, F. K., and R. B. Perry, A Method of Determining Total U²³⁵ in Flat Configurations, COO-272 (Nov 1960).
- 2. Beyer, N. S., Nondestructive Fuel Assay with Emphasis on Scintillation Spectrometry, Paper No. 23, Nuclear Congress, 1962, Engineers Joint Council, 35 E. 47 St., New York 17, N. Y.
- 3. McGonnagle, W. J., and R. B. Perry, Analysis of Fuel Element Core Blanks for Argonne Low Power Reactor by Gamma Counting, ANL-5944 (Dec 1959).
- 4. Beyer, N. S., R. B. Perry, and B. Geren, Nondestructive Analysis by Radiation Detection of Fuel Content, Fuel Homogeneity, and Surface Contamination of the Superheater Plates for the BORAX-V Reactor, ANL-6746 (to be published).

not objectionable to eacrifue several samples for destructive analysis. An alternative method of standardidation is rabrication of standard fuel elements on simulated fuel elements. For example, standards for 0.07e2-cm diameter atuminum-uranium siley ware were made by absorbing uranyi nitrate solution into nylon string of the same diameter. If the range of Utilicontent is not more than 5 to 10% from the average, two standards are usually sufficient for eslibration. If the range is much larger a linear function cannot be assumed and additional standards are necessary.

IV. URANIUM DISTRIBUTION IN DISPERSION AND ALL OF PURIS

Distribution of uranium in dispersion or alloy-type fuels can be measured by scintillation spectrometry by counting smell areas of the mel and comparing the count rate with the average count rate. The average count rate for the sample can be determined by scanning the entire sample. For measuring the distribution of uranium it is advantageous to use the entire gamma spectrum, so that the desired accuracy can be obtained in the shortest counting time. A disadvantage of the technique is that thickness changes cannot be distinguished from inhomogeneity in the dispersion or alloy.

REFERENCES

- White, F. K., and R. B. Perry, A Method of Determining Total U²³⁵ in Flat Configurations, COC-272 (Nov 1950).
- 2. Beyer, N. S., Nondestructive Fuel Assay with Emphasis on Scintillation Spectrometry, Paper No. 23, Nuclear Congress, 1962, Engineers Joint Council, 35 E. 47.St., New York 17, N. Y.
 - McGonnagle, W. J., and R. B. Perry, Analysis of Fuel Element Core Blanks for Argonne Lew Power Reactor by Gamma Counting, ANL-2944 (Dec 1959).
 - Bever, N. S., R. B. Perry, and B. Geren, Nondestructive Analysis by
 Recatation Detection of Fuel Content. Fuel Homogeneity, and Surface
 Contention tion of the Superheater Plates for the BORAX-V Reactor:
 ANL-6746 (to be published).



N