

Reactor Metrology for TREAT Experiments

Tommy V Holschuh, Scott M Watson,
James T Johnson, David L Chichester

March 2020



The INL is a U.S. Department of Energy National Laboratory
operated by Battelle Energy Alliance

Reactor Metrology for TREAT Experiments

Tommy V Holschuh, Scott M Watson, James T Johnson, David L Chichester

March 2020

**Idaho National Laboratory
Idaho Falls, Idaho 83415**

<http://www.inl.gov>

**Prepared for the
U.S. Department of Energy
Under DOE Idaho Operations Office
Contract DE-AC07-05ID14517**

Reactor Metrology for TREAT Experiments

Tommy Holschuh

Scott Watson

Jimmy Johnson

David Chichester

Radiochemistry and Nuclear Measurements
Idaho National Laboratory

19 February 2020

INL/MIS-20-57521

www.inl.gov



Overview

- TREAT Reactor Metrology (RMet) divided into two areas
 - Flux Wires
 - Ti, Fe, Co, Ni, Nb...
 - Fission Wires
 - DU, 19.43% UZr
- Flux wires give information about the neutron spectrum in a location of the reactor
 - Each isotope has different neutron interaction cross sections
 - Show deviations in spectrum compared to simulation
- Fission wires provide number of fissions in a location of the reactor
 - Using mass of wire and reactor energy → Energy Coupling Factor

Flux Wires

Fission Wires

Flux Wires

Fission Wires

Flux Wires

- Objective
 - Determine neutron energy spectrum
- Steps
 - Choose Wire
 - (Jim, Tommy)
 - Perform MCNP simulation to estimate neutron energy spectrum
 - (Jim, Kellen)
 - Irradiate wires in chosen position
 - (Kellen)
 - Count flux wire with detector
 - (Scott, Tommy)
 - Calculate activity for each flux wire
 - (Tommy)
 - Use software to “adjust” MCNP spectrum using calculated activities
 - (Tommy)

Flux Wires – Choose Wire


- Parent nuclide will have cross section of interest
 - n, gamma
 - n, p
 - n, alpha
 - n, n'
 - n, 2n
- Most useful wires would have multiple reactions
- Resulting daughter nuclide must be radioactive
- For gamma spectroscopy, must emit a gamma-ray
 - i.e. Sr-90 is beta only
- Half-life of usable value
 - Desirable to measure nuclide with half-life on order of decay time between irradiation and measurement
- Wire selection may change depending on reactor
 - TREAT is very thermal (which changes with temperature)

Flux Wires


| Parent Isotope (Activation Wires) | Density (g/cc) | Natural Isotopic Abundance (%) | Daughter Isotope | Reaction Type |
|--------------------------------------|-------------------|-----------------------------------|---------------------|------------------------|
| Ti-46 | 4.506 | 8.25 ± 0.03 | Sc-46 | Fast (n, p) |
| Ti-47 | | 7.44 ± 0.02 | Sc-47 | Fast (n, p) |
| Ti-48 | | 73.72 ± 0.03 | Sc-48 | Fast (n, p) |
| Fe-54 | 7.874 | 5.845 ± 0.035 | Mn-54 | Fast (n, p) |
| Fe-58 | | 0.282 ± 0.004 | Fe-59 | Thermal (n, γ) |
| Co-59 (Al-0.1%Co) | 8.9 (2.706) | 100 (0.1) | Co-60 | Thermal (n, γ) |

| Daughter Isotope | Half Life | Decay Photon Energy (keV) | Absolute Yield (%) |
|---------------------|-----------------------|------------------------------|----------------------|
| Sc-46 | 83.79 ± 0.04 d | 889.277 ± 0.003 | 99.984 ± 0.001 |
| | | 1120.545 ± 0.004 | 99.987 ± 0.001 |
| Sc-47 | 3.3492 ± 0.0006 d | 159.381 ± 0.015 | 68.3 ± 0.4 |
| Sc-48 | 43.67 ± 0.09 h | 983.526 ± 0.012 | 100.1 ± 0.6 |
| | | 1037.522 ± 0.012 | 97.6 ± 0.7 |
| | | 1312.12 ± 0.012 | 100.1 ± 0.7 |
| Mn-54 | 312.20 ± 0.20 d | 834.848 ± 0.003 | 99.976 ± 0.001 |
| Fe-59 | 44.495 ± 0.009 d | 1099.245 ± 0.003 | 56.5 ± 1.8 |
| | | 1291.590 ± 0.006 | 43.2 ± 1.4 |
| Co-60 | 1925.28 ± 0.14 d | 1173.228 ± 0.003 | 99.85 ± 0.03 |
| | | 1332.492 ± 0.004 | 99.9826 ± 0.0006 |

Flux Wires




Flux Wires



Flux Wires – Perform MCNP Simulation

- MCNP neutron tallies separated into energy bins will change depending on position in core
 - Center test position (M8, BUSTER)
 - Coolant channel (SPNDs)
 - Axial location
- Simulation may not accurately capture all phenomenon
 - It does its best
- Steady-state code package
 - Neutron spectrum does not change with time (temperature)
 - Does not incorporate control rod movements during reactor operations

Flux Wires





Flux Wires – Calculate Activity



- TREAT Reactor Metrology Lab is located in IRC B5 laboratory
 - Consists of one (or more) High-Purity Germanium (HPGe) detectors
 - Detectors are well-characterized
 - Calibration checks are performed routinely
 - Activity per gram of each irradiated flux wire is calculated from counting of gamma-rays emitted in characteristic peaks
-
- A = Activity per gram of parent isotope (Bq/g)
 - λ = Decay constant (sec^{-1})
 - C = Counts in photopeak for radionuclide
 - t_d = Decay time between EOI and start of count (sec)
 - η = Quantum yield of gamma-ray per disintegration
 - ε = Absolute efficiency of detector at photopeak energy
 - g = Self-shielding factor
 - m = Mass of parent isotope (g)
 - t_r = Real counting time (sec)

$$A = \frac{\lambda C e^{\lambda t_d}}{\eta \varepsilon g m (1 - e^{-\lambda t_r})}$$

Flux Wires






Flux Wires



Flux Wires – Calculate Activity

- Largest effort is absolute efficiency for wire
 - Irradiated wire is counted
 - Check source used to calibrate detector (Eu-152)
 - Efficiency of detector as function of energy
 - MCNP model of check source is created, compared (Eu-152)
 - MCNP bias (<5%)
 - MCNP model of irradiated wire is created
 - Wire geometry is different from check source
 - Results are adjusted by MCNP bias
 - Efficiency for irradiated wire's gamma rays in detector measurement is determined
- MCNP wire model must be performed for each unique wire/distance combination



Flux Wires




Flux Wires – STAYSL

- PNNL STAYSL software package uses measured wire activities to “adjust” a guessed spectrum
 - Typically, wire activities are reported to end of irradiation (EOI)
 - STAYSL requires saturated activity in its calculation
 - MCNP provides hundreds of neutron groups
 - But typically less than 10 wire reactions are available
 - Solves with cross section data and covariance matrix
 - An underdetermined matrix
- STAYSL is very sensitive to initial MCNP “guess” for spectrum
- What usable information can STAYSL provide?
 - Relative correction for axial position
 - Ratio of thermal/fast fluence
 - Absolute neutron spectrum?

Flux Wires



Flux Wires – Conclusion



Flux Wires

Fission Wires

Fission Wires


- Objective
 - Determine total fissions (or coupling factor) for a given test position

- Steps
 - Choose Wire
 - (Jim)
 - Irradiate wires in chosen position
 - (Kellen)
 - Count fission wire with detector
 - (Scott, Tommy)
 - Calculate number of fissions (or coupling factor)
 - (Tommy)


Fission Wires – Choose Wire

- Currently at TREAT, two choices for fission wires
 - Depleted uranium (DU) metal
 - TREAT has a large inventory
 - Low-enriched uranium-zirconium alloy (19.43% enriched UZr)
 - Higher melting point
 - Lower fraction of threshold fission from U-238
 - Inventory limited (legacy material)
- Characterization of fission products from U-235

Fission Wires



Fission Wires



Fission Wires – Calculate Fissions

- Only one fission product is necessary to calculate the number of fissions
 - More fission products allow for a lower uncertainty to be determined
- For gamma spectroscopy, fission products must emit a gamma-ray
- Half-life of usable value
 - Desirable to measure nuclide with half-life on order of decay time between irradiation and measurement
- Avoid gases (I-131, I-132, Xe-135)
- With UZr fission wire, zirconium fission products and their daughters cannot be used
- Uranium has a K-edge around 140 keV, attenuation in this region can be difficult (i.e. Tc-99m)
 - Avoid using gamma-rays less than ~200 keV

Fission Wires

- N = Number of fissions per gram of fissile isotope Activity per gram of parent isotope (Bq/g)
- C = Counts in photopeak for radionuclide
- λ = Decay constant (sec^{-1})
- t_d = Decay time between EOI and start of count (sec)
- F = Time-corrected fission yield
- η = Quantum yield of gamma-ray per disintegration
- ϵ = Absolute efficiency of detector at photopeak energy
- g = Self-shielding factor
- m = Mass of parent isotope (g)
- t_r = Real counting time (sec)

$$N = \frac{C e^{\lambda t_d}}{F \eta \epsilon m g (1 - e^{-\lambda t_r})}$$

| Isotope | Half Life | Photon Peaks of Interest (keV) | Absolute Photon Yield per Disintegration (%) |
|-------------------|--|--------------------------------|--|
| Zr-95 | 64.032 \pm 0.006 d | 756.725 \pm 0.012 | 54.38 \pm 0.22 |
| Nb-95 | 34.991 \pm 0.006 d | 765.803 \pm 0.006 | 99.808 \pm 0.007 |
| Mo-99 | 65.924 \pm 0.006 h | 739.500 \pm 0.017 | 12.20 \pm 0.16 |
| Tc-99m (Mo-99) | 6.0072 \pm 0.0009 h | 140.511 \pm 0.001 | 89 \pm 4 |
| Ru-103 | 39.247 \pm 0.013 d | 497.085 \pm 0.010 | 91.0 \pm 1.2 |
| I-131 | 8.0252 \pm 0.0006 d | 364.489 \pm 0.005 | 81.5 \pm 0.8 |
| I-132 (Te-132) | 2.295 \pm 0.013 h (3.204 \pm 0.013 d) | 522.65 \pm 0.09 | 16.0 \pm 0.5 |
| Ba-140 | 12.7527 \pm 0.0023 d | 537.261 \pm 0.009 | 24.39 \pm 0.22 |
| La-140 | 1.67855 \pm 0.00012 d | 487.021 \pm 0.012 | 45.5 \pm 0.6 |
| Nd-147 | 10.98 \pm 0.01 d | 531.016 \pm 0.022 | 13.4 \pm 0.3 |

Fission Wires – Calculate Fissions

- Largest effort is absolute efficiency for wire
 - Irradiated wire is counted
 - Check source used to calibrate detector (Eu-152)
 - Efficiency of detector as function of energy
 - MCNP model of check source is created, compared (Eu-152)
 - MCNP bias (<5%)
 - MCNP model of irradiated wire is created
 - Wire geometry is different from check source
 - Results are adjusted by MCNP bias
 - Efficiency for fission product's gamma rays in detector measurement is determined
- MCNP wire model must be performed for each unique wire/distance combination

Fission Wires – Calculate Coupling Factor


- Energy Coupling Factor (ECF) normalizes the fissions based on wire mass and total reactor energy released
 - Traditionally termed the power coupling factor (PCF)

$$J = \text{fissions} \times \frac{\text{MeV}}{\text{fission}} \times \frac{1.602e-13 \text{ J}}{\text{MeV}}$$

$$ECF \equiv \frac{\text{Energy deposited in sample}}{(\text{material mass})(\text{Reactor Energy})} = \frac{J}{g - MJ}$$

- Q-value must be determined
 - In TREAT, value is 182 MeV/fission – see Jim Parry
 - In fuel, this value could be different (~190-200 MeV)
- ECF is compared to simulation with MCNP and/or appropriate MOOSE package


Fission Wires – Conclusion




TREAT Reactor Metrology Fuel Measurements

- The methodology for fission wires can be extended to larger fission materials
 - SETH-A
 - ECF calculation
 - Gamma Scan (Jimmy)
 - Aqua-SETH
 - ECF calculation for entire rodlet
 - Gamma Scan – half submerged in water – ECF by pellet
 - Increase in ECF compared to dry environment
 - M-SERTTA
 - ECF calculation for entire rodlet
 - Gamma Scan – change due to enrichment – ECF by pellet
 - Changed set-up slightly and can perceive individual pellets within rodlet



Aqua-SETH Measurements



| Pellet | ECF (J-g/MJ) | Unc (k=2) | Ratio to Pellet #9 |
|--------|--------------|-----------|--------------------|
| 1 | 0.828 | 0.074 | 2.055 |
| 2 | 0.874 | 0.079 | 2.168 |
| 3 | 0.864 | 0.078 | 2.143 |
| 4 | 0.825 | 0.074 | 2.047 |
| 5 | 0.729 | 0.064 | 1.809 |
| 6 | 0.563 | 0.049 | 1.396 |
| 7 | 0.448 | 0.039 | 1.113 |
| 8 | 0.417 | 0.036 | 1.034 |
| 9 | 0.403 | 0.034 | 1.000 |
| 10 | 0.366 | 0.031 | 0.908 |




M-SERTTA Measurements



TREAT Reactor Metrology Fuel Measurements

- 4 inches of tungsten shielding + 1.5 +/- .25 mm fuel offset
- 1 mm slit width
- 2700 second dwell
- 1 mm step size
- Start Position 73 mm
- End Position 260 mm

These three points were recorded in a subsequent data set on a different day.



TREAT Core Map

| | A | B | C | D | E | F | G | H | J | K | L | M | N | O | P | R | S | T | U |
|----|-----|-----|-----|-----|-----|-----|-----|-----|-----|---------|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| 1 | ZRD | ZRD | 108 | 398 | 283 | 324 | 247 | 319 | 408 | H01 | 289 | 140 | 356 | 271 | 178 | 366 | 313 | ZRD | SRC |
| 2 | ZRD | 169 | 305 | 391 | 128 | 393 | 294 | 213 | 236 | H02 | 224 | 285 | 115 | 383 | 358 | 367 | 196 | 198 | ZRD |
| 3 | 522 | 147 | 221 | 384 | 303 | 244 | 203 | 702 | 217 | H03 | 186 | 728 | 164 | 142 | 161 | 342 | 346 | 286 | 287 |
| 4 | 194 | 298 | 382 | 314 | 389 | 701 | 145 | 183 | 257 | H04 | 207 | 165 | 291 | 718 | 127 | 405 | 353 | 284 | 360 |
| 5 | 348 | 388 | 171 | 295 | 260 | 175 | 249 | 138 | 179 | H05 | 173 | 344 | 302 | 117 | 120 | 148 | 182 | 312 | 399 |
| 6 | 155 | 369 | 226 | 700 | 230 | 228 | 231 | 241 | 296 | H06 | 214 | 118 | 341 | 256 | 297 | 712 | 263 | 381 | 362 |
| 7 | 396 | 152 | 211 | 222 | 317 | 216 | 280 | 136 | 149 | H07 | 197 | 269 | 277 | 215 | 156 | 242 | 253 | 177 | 349 |
| 8 | 328 | 141 | 726 | 258 | 121 | 722 | 160 | 321 | 114 | H08 | 343 | 336 | 170 | 723 | 264 | 172 | 705 | 407 | 329 |
| 9 | 248 | 167 | 254 | 332 | 377 | 412 | 206 | 204 | 281 | H21 | 378 | 229 | 309 | 279 | 403 | 300 | 157 | 116 | 272 |
| 10 | 347 | 133 | 113 | 112 | 359 | 290 | 210 | 340 | 166 | M-8 Cal | 322 | 104 | 416 | 282 | 529 | 106 | 310 | 306 | 414 |
| 11 | 395 | 129 | 239 | 331 | 190 | 163 | 275 | 259 | 371 | H2D | 126 | 223 | 372 | 523 | 202 | 252 | 135 | 245 | 386 |
| 12 | 392 | 397 | 729 | 278 | 262 | 716 | 243 | 530 | 185 | 153 | 209 | 233 | 304 | 721 | 192 | 292 | 714 | 413 | 355 |
| 13 | 102 | 311 | 123 | 238 | 323 | 250 | 330 | 526 | 502 | 521 | 500 | 503 | 531 | 417 | 265 | 237 | 246 | 288 | 299 |
| 14 | 318 | 232 | 240 | 711 | 184 | 154 | 159 | 137 | 501 | 528 | 527 | 525 | 101 | 109 | 334 | 713 | 357 | 273 | 333 |
| 15 | 387 | 168 | 401 | 132 | 187 | 119 | 144 | 327 | 201 | 122 | 520 | 370 | 199 | 227 | 208 | 220 | 320 | 143 | 162 |
| 16 | 351 | 415 | 406 | 364 | 111 | 717 | 189 | 255 | 174 | 301 | 110 | 200 | 293 | 720 | 100 | 394 | 326 | 124 | 139 |
| 17 | 107 | 361 | 379 | 363 | 103 | 146 | 180 | 724 | 195 | 130 | 150 | 703 | 188 | 225 | 380 | 338 | 266 | 131 | 375 |
| 18 | ZRD | 385 | 308 | 365 | 205 | 402 | 151 | 181 | 307 | 212 | 352 | 218 | 125 | 390 | 404 | 374 | 235 | 368 | ZRD |
| 19 | ZRD | ZRD | 191 | 409 | 315 | 337 | 134 | 373 | 339 | 251 | 335 | 354 | 176 | 345 | 400 | 234 | 325 | ZRD | ZRD |

- Red – Fuel Assemblies
- Yellow – Control Rods
- Green – Slotted Assemblies for Hodoscope
- Black – Graphite Dummy Assemblies
- Purple – Test Position