

Reactivation of the Transient Reactor Test (TREAT) Facility Neutron Radiography Program

Shawn R Jensen, Dr. Aaron E. Craft

September 2018



The INL is a U.S. Department of Energy National Laboratory
operated by Battelle Energy Alliance

Reactivation of the Transient Reactor Test (TREAT) Facility Neutron Radiography Program

Shawn R Jensen, Dr. Aaron E. Craft

September 2018

**Idaho National Laboratory
Idaho Falls, Idaho 83415**

<http://www.inl.gov>


**Prepared for the
U.S. Department of Energy**

**Under DOE Idaho Operations Office
Contract Unknown**


Reactivation of the Transient Reactor Test (TREAT) Facility Neutron Radiography Program

TREAT Reactor

- Construction for the Transient Reactor Test (TREAT) Facility began in February 1958 and reached initial criticality in February 1959
- Designed for steady-state irradiation and high power transient testing of materials, including new and used nuclear fuels



- The core is air cooled, graphite moderated, and highly configurable
- Capable of 120 kW steady-state and up to 19,000 MW peak transient power levels to simulate off-normal conditions
- Placed in shutdown status in 1994 and successfully restarted in November 2017





Authors and Acknowledgements

This poster was prepared by Shawn Jensen with contributions and support from Dr. Aaron Craft, Glen Papaioannou, Blaine Ward, Wyatt Empie, Brandon Moon, and other INL staff.

Radiography Facility and Upgrades




- Performs neutron radiography of fuels, experiments, and other specimens before and after irradiation
- First neutron radiograph obtained in 1967
- Acquired over 5,000 radiographs by 1977
- The neutron beam is radial to the core and contains thermal and epithermal neutrons
- Capable of imaging specimens 10cm x 20cm and up to 4 m long
- Utilizes transfer method neutron radiography with dysprosium or indium conversion foils and computed radiography image plates



- Upgraded the stand and drive system in 1975-76 providing additional shielding and remote operating capabilities
- Structural upgrades in 1984 increased the load carrying capacity to 44 metric tons to accommodate larger casks
- Installed a remote aperture assembly in 1986 allowing for two different aperture sizes allowing for different collimation ratios
- Recently upgrades include: shielding oil recovery system, external shielding and seismic bracing, electro-mechanical to electronic exposure timer conversion, dedicated room for image preparation and processing, and installation of a computed radiography system


Neutron Beam Characterization

- Measured neutron flux by irradiated 21 gold foils for 3 hours at 80 kW then measured activity using a calibrated high-purity germanium detector
- From the measured activities, the average neutron flux was calculated to be $8.25 \times 10^6 \pm 1.89 \times 10^5 \text{ n/cm}^2\text{s}$
- Neutron energy spectrum will be quantified using foil activation techniques with multiple foil materials
- Beam uniformity was measured using a radiograph of the open beam
- The peak-to-average ratio is 1.006 (horizontal) and 1.011 (vertical) indicating a uniform beam profile



Determining Exposure and Decay Times and Effective Resolution

- Three sets of qualification radiographs were taken of a Resolution Test Piece (RTP) containing ASTM Sensitivity Indicator and Beam Purity Indicator along with gadolinium and hafnium edge specimens
- Used transfer method neutron computed radiography (nCR) with dysprosium conversion foil and Carestream general purpose (GP) and high resolution (HR) image plates
- Exposure times greater than 10 minutes showed diminished peak pixel and Signal-to-Noise Ratio (SNR) values using GP plates
- Programmatic quality radiographs using 10 minute exposure and 120 minute decay times provided 94% of peak SNR using GP plates
- Information-only quick-shot radiographs using 10 minute exposure and 20 minute decay times provided 60% of peak SNR using GP plates
- The effective spatial resolution seems unaffected by exposure time
- Additional analysis using HR plates will be conducted in the future



10 minute exposure with 120 minute decay

10 minute exposure with 20 minute decay