



# Design Features of TMIST-3 Experiments that Assist with Tritium Management

May 2022

*Changing the World's Energy Future*

Craig S Biebel



#### **DISCLAIMER**

This information was prepared as an account of work sponsored by an agency of the U.S. Government. Neither the U.S. Government nor any agency thereof, nor any of their employees, makes any warranty, expressed or implied, or assumes any legal liability or responsibility for the accuracy, completeness, or usefulness, of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights. References herein to any specific commercial product, process, or service by trade name, trade mark, manufacturer, or otherwise, does not necessarily constitute or imply its endorsement, recommendation, or favoring by the U.S. Government or any agency thereof. The views and opinions of authors expressed herein do not necessarily state or reflect those of the U.S. Government or any agency thereof.

# **Design Features of TMIST-3 Experiments that Assist with Tritium Management**

**Craig S Biebel**

**May 2022**

**Idaho National Laboratory  
Idaho Falls, Idaho 83415**

**<http://www.inl.gov>**

**Prepared for the  
U.S. Department of Energy  
Under DOE Idaho Operations Office  
Contract DE-AC07-05ID14517, DE-AC07-05ID14517, DE-AC07-05ID14517, DE-  
AC07-05ID14517**



May 10, 2022

**Craig Biebel**

Irradiation Experiment Design Engineer

# Design Features of TMIST-3 Experiments that Assist with Tritium Management




# Overview

- Tritium background
- TMIST-3 experiment overview
- Permeation through components
- Leakage through connections
- Leakage to outside environment
- Radiological control measures
- Summary
- Acknowledgements

# Tritium Background


- Tritium is radioactive hydrogen
  - Decays to  $^3\text{He}$  by low energy beta radiation
  - 12.3 year half-life
  - Required for nuclear weapons stockpile
  - Potential fusion reactor fuel
- Tritium is difficult to contain
  - Leakage through connections
  - Permeation through components (exacerbated by heat & irradiation)
- Tritium management in TMIST experiments:
  - Transported into experiment from external supply (TMIST-2, TMIST-4)
  - Generated or liberated from within experiment (**TMIST-3**, TMIST-4)
  - Transported out of experiment to external monitors (TMIST-2, **TMIST-3**, TMIST-4)



# TMIST-3 Experiment Overview:

## Tritium-Producing Burnable Absorber Rod

Part of a series of experiments to improve understanding of TPBAR performance






# TMIST-3 Experiment Overview:

## TPBAR Materials Irradiation Separate Effects Test 3

Collaboration between PNNL and INL

### Pellet Performance Test Objectives:

- Measure tritium release as function of temperature, time, burnup, burnup rate
- Quantify speciation of tritium release ( $T_2O$  vs.  $T_2$ ) as function of time, burnup, burnup rate
- Evaluate effects of pellet grain size and porosity on tritium release
- Evaluate pellet performance to burnup values exceeding current design
- Evaluate alternate pellet materials





# TMIST-3 Experiment Overview:

## *TMIST-3A vs. TMIST-3B*


- Originally designed to be irradiated simultaneously
- Irradiated sequentially due to budget challenges

### TMIST-3A



- Short-term / low burnup
- ~300 days in position I-13
- 2016-2019
- 13 Closed capsules
- 9 Flow-through capsules
- 43 Gas tubes
- 16 Thermocouples
- 7 Flux monitors

### TMIST-3B

- Long-term / high burnup
- ~550 days in position I-9
- 2019-CIC-2023
- 13 Closed capsules
- 6 Flow-through capsules
- 34 Gas tubes
- 18 Thermocouples
- 7 Flux monitors




# TMIST-3 Experiment Overview: Capsule Arrangement and Instrumentation



# TMIST-3 Experiment Overview:



## *Capsule Support Cage Assembly*






# Permeation Through Components: *Material Selection*

- Type 304L stainless steel used in core region
  - Recommended by DOE-STD-1129
  - Good service temperature
  - Corrosion resistant
  - Common in reactor systems
  - Reactor coolant pressure boundary, capsules, gas tubing



# Permeation Through Components: *Material Selection*



- Type 122 copper gas tubing used inside leadout above core region
  - Lower tritium permeability than stainless
- Copper design challenges:
  - Lower service temperature than stainless steel
  - Requires brazing (instead of welding) to join to SST
  - Lower melting point limits braze filler metal selection (and service temp.)
  - Different mechanical connections (e.g. brass vs. SST)
  - Requires isolation from reactor coolant due to PCS chemistry limits on copper (when leadout is severed during post-irradiation sizing)





# Leakage Through Connections: *Minimize Connections*

- Minimize number of connections
  - Maximum length of gas tubing in experiment ~30 feet
  - Long coils of tubing were used to avoid connecting shorter sections together



Leadout

Core




# Leakage Through Connections: *Selection of Connection Type*

- Metallic connections were used (tolerate higher temperature and radiation)
  - Welded or brazed connections preferred
    - More compact
    - Robust
    - More leak tight(?)
    - More difficult to repair
  - Mechanical connections (Swagelok VCR & compression) used where necessary
    - Reversible process
    - Good service history


SST-to-Cu transition  
brazed sleeve



Metallic  
crush gasket



Metallic  
ferrules





# Leakage Through Connections: *Brazing SST-to-Copper Gas Tubes*


Quartz glass  
tube

Copper gas  
tube


Braze filler  
powder

SST sleeve

Induction  
coil



CT scan of  
practice braze



Brazed  
transition sleeve






Coiled SST-Cu  
tube assembly






# Leakage Through Connections: *Brazing SST-to-SST Capsules*






# Leakage Through Connections: *Swagelok Compression Fittings*





Swagelok  
compression fittings



Top end of TMIST-3B  
leadout




# Leakage Through Connections: *Swagelok Compression Fittings*





# Leakage Through Connections: *Leak Testing*




- Leak test connections during assembly after each new connection
  - Helium mass spectrometer
  - Special test fixtures, seals, “bell jars”






# Leakage from Leadout to Outside Environment

- Bulkheads in leadout isolate interior from outside environment
  - Prevent reactor coolant leakage from hypothetical failure of experiment pressure boundary
  - Enable control of atmosphere inside leadout (helium purge)
    - Control heat transfer in core section
    - Monitor for pressure boundary leaks (moisture, pressure)
    - Remove tritium that accumulates in leadout



# Radiological Control Measures: *Biological Hazard*




- Gaseous tritium (HT, T<sub>2</sub>) is not readily absorbed by body
  - Only a small fraction retained in lungs if inhaled

- Aqueous tritium (HTO, T<sub>2</sub>O) (liquid or vapor) is readily absorbed through skin & lungs
  - 10 day half-life inside body
  - Tritiated water/vapor is 10,000 times more hazardous than gaseous tritium



# Radiological Control Measures: *Monitoring & Ventilation*

- Bioassay (urinalysis) before & after work
- Monitor airborne tritium during gas tube connections (transition from experiment to ex-reactor gas monitoring system)
  - Handheld meter with extension tube
  - Perform one connection at a time
- Use localized exhaust ventilation to draw air away from worker breathing zone
  - Exhaust trunk with air handler connected to facility ventilation system



# Summary

## TMIST-3 design features that assist with tritium management:

- Copper gas tubing used above core region
- Number of connections minimized
- Metallic connections used
  - Welded > brazed > mechanical
- Leak tested connections during assembly
- Leadout interior purged during irradiation
- Radiological control measures during installation/removal
  - Bioassay program
  - Airborne monitoring during gas tube connections
  - Use localized exhaust ventilation

# Acknowledgements

- PNNL Tritium Technology Program team
- DOE-STD-1129-2015, *DOE Standard for Tritium Handling and Safe Storage*
  - Publicly available: <https://www.standards.doe.gov/standards-documents/1100/1129-AStd-2015>



# Idaho National Laboratory

*Battelle Energy Alliance manages INL for the U.S. Department of Energy's Office of Nuclear Energy. INL is the nation's center for nuclear energy research and development, and also performs research in each of DOE's strategic goal areas: energy, national security, science and the environment.*

WWW.INL.GOV