



X-ray Computed Tomography of Irradiated and Unirradiated AGR-3/4 Compacts A preliminary examination

July 2022

Changing the World's Energy Future

Joshua J Kane



DISCLAIMER

This information was prepared as an account of work sponsored by an agency of the U.S. Government. Neither the U.S. Government nor any agency thereof, nor any of their employees, makes any warranty, expressed or implied, or assumes any legal liability or responsibility for the accuracy, completeness, or usefulness, of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights. References herein to any specific commercial product, process, or service by trade name, trade mark, manufacturer, or otherwise, does not necessarily constitute or imply its endorsement, recommendation, or favoring by the U.S. Government or any agency thereof. The views and opinions of authors expressed herein do not necessarily state or reflect those of the U.S. Government or any agency thereof.

X-ray Computed Tomography of Irradiated and Unirradiated AGR-3/4 Compacts A preliminary examination

Joshua J Kane

July 2022

**Idaho National Laboratory
Idaho Falls, Idaho 83415**

<http://www.inl.gov>

**Prepared for the
U.S. Department of Energy
Under DOE Idaho Operations Office
Contract DE-AC07-05ID14517**

July 12, 2022

Joshua Kane

Data Analysis & Visualization Lead

INL, Char. & Adv. PIE Division

X-ray Computed Tomography of Irradiated and Unirradiated AGR-3/4 Compacts

A preliminary examination

What and Why?


- **What?**

- Performed X-ray CT (XCT) on irradiated AGR-3/4 compacts
 - Apparatus design
 - Imaging results
 - Preliminary analysis
 - Extruded kernels
 - DTF Identification

- **Why?**

- Can provide non-destructive 3D perspective to enhance/compliment current PIE
 - Potentially better quantitative measurements of certain features
 - Better means of understanding any spatial distribution(s)

X-ray Computed Tomography (XCT)




Compacts Examined



- **AGR-3/4 compacts**
 - Compact Dimensions:
 - Length- ~12.5 mm
 - Diameter- ~12.3 mm
 - Particles:
 - ~1898 TRISO-coated driver particles
 - **20** Designed To Fail (DTF) particles
- **Examined 2 Irradiated Compacts and 2 Unirradiated Compacts**

Irradiated Compact Details:

Compact ID	Capsule #	Compact Position	Burnup (% FIMA)	Fast Neutron Fluence ($\times 10^{25}$ n/m ² , E>0.18 MeV)	Temperature (°C) ^a
12-4	12	4	4.85	1.19	845
7-1	7	1	14.92	5.28	1276



Driver



DTF



Imaging Challenge

Irradiated Compact:

Compact ID	γ dose (mrem/hr)*	γ dose (mrem/hr)+	β dose (mrem/hr)*	β dose (mrem/hr)+
12-4	3,100	350	23,700	3,150
7-1	12,000	800	>50,000	3,900



*- Dose at contact with sample

+ - Dose at 30 cm from sample

- **Possible Challenges**





- Minimizing dose to handling personnel and instrumentation
 - Significant γ dose difficult to shield for during sample handling
 - X-ray detector sensitive to γ and any x-rays generated from deaccelerating β particles
- Preventing HFEF contamination from impacting XCT system

Sample Shielding Device





X-ray Imaging Conditions


- Low and high energy scans:
 - ~40 keV X-ray energy
 - ~110 keV X-ray energy
- Source to object distance:
 - 42.03 mm
- Source to detector distance:
 - 245.6 mm
- Radiographs:
 - 5001 over 360 degrees
- Frame averaging:
 - 20 frames per radiograph
- Detector pixel pitch:
 - 75 μm
- Reconstructed pixel size:
 - 10.93 μm




The compromise for X-ray imaging of TRISO fuel



The compromise for X-ray imaging of TRISO fuel:
Fueled sample comparison to more ideal surrogate









Zirconia Kernel Surrogate TRISO





AGR-3/4 Unirradiated Compact Z104





X-ray CT Imaging Results: Compact 7-1



X-ray CT Imaging Results



Extruded Kernels Compact 7-1



Sphericity used as metric to screen extruded kernels:




Kernel Sphericity < 0.964

~33%, 635 of 1924 Kernels in 7-1 possess some degree of extrusion


From cross-sections of adjacent compact, Compact 7-2, extruded kernels resulting from buffer fracture was estimated to be 14.3% of total particles*.



DTF Identification:



Preliminary Comparison: Driver to DTF Particle Size Compact 7-1



Note that equivalent diameters may not be correct, however a relative comparison is still likely valid.

Conclusions & Planned Work

- X-ray CT demonstrated on irradiated AGR-3/4 compacts
 - Provides a means for complimentary analyses to current AGR PIE
 - Enables quantification of spatial variation in features within compact

Remaining in FY2022:

- Planning to further examine and quantify kernel dimensional change, kernel extrusions, and DTF particles.
- Examine a limited number of deconsolidated particles from AGR-5/6/7 experiment

In FY2023:

- Image additional AGR-3/4 compacts at intermediate burnups to provide a broader range of fuel conditions for comparison
- Explore imaging AGR-5/6/7 compact (More challenging due to significantly higher radiation dose)
- Refine reconstruction methodology for “low-energy” CT scans of irradiated compacts
 - Ideally would enable additional information on matrix and potential pores and cracks to be extracted

Thank you for your attention

Contact Information:

Joshua Kane

Data Analysis & Visualization Lead, CAPIE

joshua.kane@inl.gov

William Chuirazzi

X-ray CT Instrument Scientist

william.chuirazzi@inl.gov

